

TO MAKE INTERCOM / OUTGOING CALLS

To make an intercom call or an outgoing call:

Manual Mode

1. Press the [Answer] button on the headset.
2. Press Extension Number or dial External number
3. To End Call press [Answer] button on headset

Auto Mode

Press Extension number or dial External number
To End Call press SPK button on DK2 Phone

GENERAL OPERATION

To Adjust Speaker Volume during a Call

You can adjust the speaker volume during a call by pressing the volume control buttons on the side of the Ear and or the volume control keys on the DK2 phone according to your preference.

Operation Range

The Hybrex DK2 Blue Tooth Interface is a very low power radio communication device. The radio communication range between the DK2 and the Headset is approximately 10 meters. Please keep both units within this range for best communication performance.

EAR PIECE SETUP

Most headsets will allow you to wear the headset on your right or left per your preference. Please consult your Blue Tooth Headset user guide for the setup required.

MAINTAINANCE

As high temperature will shorten the battery life, please do not leave your Headset in an environment with temperatures over 100°F or in direct sunlight.

Keep your Headset away from moisture.

To clean, use soft cloth with mild liquid soap to clean the exterior of your Cordless Headset and phone. DO NOT

use abrasive chemical detergent or material to clean the Headset.

DO not attempt to pry open the cover of your Cordless Headset or change the batteries. Seek assistance from an AUTHORIZED Hybrex dealer near you.

WARRANTY SCOPE

Auto Telecom guarantees our products (excluding the batteries) as being free of defects in material, design and workmanship at the time of original purchase and for a period of twelve (12) months immediately thereafter.

If, during the warranty period, the products malfunction in normal use and service (by authorized dealer), Auto Telecom or its authorized dealer will repair or replace the defective product at no cost to the original purchaser.

Auto Telecom or its authorized dealer may refuse to provide free warranty service if any of the following conditions occurs:

1. The product is adapted, modified, or changed.
2. The product exterior is cracked or broken.
3. The serial number label is tampered with or missing.
4. The product has being misused by the user in any way.
5. The product has not being serviced by a Hybrex AUTHORED service agent

Repairs or replacements will neither give any right to extend the original warranty period nor give any right to start a new warranty period. Replaced faulty parts or components will become the property of Auto Telecom.

HEADSET SPECIFICATIONS

Frequency	2.400~2.4835GHz
Security	128 Bit
Technology Type	Blue Tooth
Auto channel hopping	Yes
Working range	Up to 10 meters
Talk time	4 hours (headset dependant)
Blue Tooth Version	1.2



Blue Tooth Phone User Guide

Auto Telecom New Zealand Ltd

Ph (09) 268 8214

Fax (09) 268 8389

BLUE TOOTH HEADSETS

The Hybrex DK2 Phone Blue Tooth interface will integrate with many brands of headset, Hybrex have tested and recommend the following headsets



Motorola HS820



Motorola HS810



Netcom GN6110

CONNECTION TO PHONE

No physical connection to the DK2 phone is required.

TO PAIR HEADSET WITH DK2 PHONE

Before Pairing:

Please ensure Blue Tooth Headset has had its first maximum charge as recommended by its manufacturer.

- Hold Headset with Mic Boom closed
- Place Blue Tooth Headset into Pairing Mode by pressing and holding down the answer key until LED light comes on
- Open Mic Boom, LED on Headset should remain on
- Press and hold down the DK2 phones "HOLD" key until "Pairing" is displayed on phone screen
- Release Hold Key
- Waiting until Blue Tooth Headset LED flashes rapidly
- Phone and Handset are now Paired

Note: Please ensure you only pair one Blue Tooth Device in the area of work at any one time

TO ACTIVATE DK PHONE INTO HEADSET MODE

To activate the headset mode on DK2 phone:

- Press [SPK][775] to enable the headset mode.

To cancel the headset mode on DK2 phone:

- Press [SPK][775] to cancel the headset mode.

TO ANSWER INCOMING CALLS

Manual Mode

To answer incoming call:

- When DK2 phones rings the Blue Tooth Headset will beep in your ear
- To answer call press the [Answer] button on the Blue Tooth headset.

To end the conversation of a call:

- Press the [Answer] button again will end the call
- The Blue Tooth Headset will beep to indicate call ended and will automatically put DK2 phone to idle state.

Note:

- If you press [SPK] button on the DK2 telephone this will also end the call directly. But the Blue Tooth Headset will be left in Auto Answer Mode". If left in this state the next incoming call will be answered automatically by the Headset.

Auto Mode

Headset will be in active when in this mode, please note the battery time will be more limited when using this mode

To answer incoming call:

- When DK2 phones rings the Blue Tooth Headset will beep in your ear once
- The Headset will then answer call

To end the conversation of a call:

- Press the SPK key on the DK2 phone

Note:

- If you press [SPK] button on the DK2 telephone will also end the call directly. But the Blue Tooth Headset will be left in Auto Answer Mode". If left in this state the next incoming call will be answered automatically by the Headset.